

## GENBOLT CAMERAS

## How to add WIFI camera to Ispy

## 1, RTSPto add

- 1、main stream: rtsp://ip address/11
- $2_{\sim}$  vice stream: rtsp://ip address/12

Find "FFMPEG (H264)" this column, fill in information of RTSP in the URL.After adding can test test is successful

JPEG URL MJPEG URL	FFMPEG (H	264) v	IC Plusia	Local Device	Desister	XIMEA	Kinect	ONVIF	Custom	Clara
URL			8. 20. 59:55		Desktop	*	Kinect	ONATL	Uustom	CIONE
Analyse Duration (ms RTSP Mode		example rtsp:// http:// c:/your	s: username:p	h to a video f assword@192.16 assword@192.16 e.mp4	8.1.10/					
P Camera With Wizard	I]							<u>Help</u>	Advance	d Cancel

Go to "Camera" option

Input your camera ip address, User name and Password, click "Finish", add camera succeed.



amera Motion Detect	ion Alerts Recording PTZ Images FTP Cloud Storage Scheduling Storage										
Video Source											
Source	Adv. Properties Inputs Options										
Name	Camera O										
Groups	Help										
	🖉 Camera Active 📄 Fill										
Transform	Rotate None Flip None 🔻										
Timestamp	FPS: {FPS} {0:G}										
Mask Image											
Picture In Picture											
Maximum Framerate	10 🚔 When Recording 10 🚖										
Microphone											
Mi crophone	None <u>Help</u>										
Talk											
Camera Model	None										
IP Address	192. 168. 20. 59 Port 80										
Vsername	admin Password ****										